




## 🍏 Apple /// Computer Technical Information

Apple ///  
RS-232 Serial Port  
Driver 1.30  
Source Code Listing



Created by David T. Craig  
07 January 1998 •  
71533.606@compuserve.com



# FORMATTED LISTING

```

; #####
; # PROJECT : Apple /// SOS RS-232 Driver 1.30 (6502 Assembly Source Code)
; # FILE NAME: RS232.text
; #####

000001          .TITLE          "SOS RS232 DRIVER"
000002
000003 ;
000004 ;          SOS RS232 DRIVER
000005 ;
000006 ;          (C)  APPLE COMPUTER 1981, 1982, 1983
000007 ;
000008 ;          Jim Trezzo      1/07/83
000009 ;
000010 ;          V 1.01  9/11/81 Clear NO_OUTPUT flag during reset
000011 ;          V 1.02  4/23/82 Don't drop DTR during reset and wait for
000012 ;                   DLYCNT before close.
000013 ;          V 1.30  1/07/83 Add comment field
000014 ;
000015
000016 DEVTYP  .EQU          63          ;I/O CHAR DEV
000017 SUBTYP  .EQU          01          ;DEV SUBTYPE
000018 MANID   .EQU          01          ;MANUFACTURER ID-APPLE
000019 RELEASE .EQU          1300       ;RELEASE NUMBER-BCD FORMAT
000020
000021 ;
000022 ; The macro SWITCH performs an N way branch based on a switch index. The
000023 ; maximum value of the switch index is 127 with bounds checking provided
000024 ; as an option. The macro uses the A and Y registers and alters the C,
000025 ; Z, and N flags of the status register, but the X register is unchanged.
000026 ;
000027 ;          SWITCH [index], [bounds], adrs_table, [*]
000028 ;
000029 ;          index This is the variable that is to be used as the switch index.
000030 ;                   If omitted, the value in the accumulator is used.
000031 ;
000032 ;          bounds This is the maximum allowable value for index. If index
000033 ;                   exceeds this value, the carry bit will be set and execution
000034 ;                   will continue following the macro. If bounds is omitted,
000035 ;                   no bounds checking will be performed.
000036 ;
000037 ;          adrs_table This is a table of addresses (low byte first) used by the
000038 ;                   switch. The first entry corresponds to index zero.
000039 ;
000040 ;          * If an asterisk is supplied as the fourth parameter, the
000041 ;                   macro will push the switch address but will not exit to
000042 ;                   it; execution will continue following the macro. The
000043 ;                   program may then load registers or set the status before
000044 ;                   exiting to the switch address.
000045 ;
000046
000047          .MACRO          SWITCH
000048          .IF             "%1" <> ""          ;If PARM1 is present,
000049          LDA             %1                   ; Load A with switch index
000050          .ENDC
000051          .IF             "%2" <> ""          ;If PARM2 is present,
000052          CMP             #%2+1               ; Perform bounds checking
000053          BCS             $010                 ; on switch index
000054          .ENDC
000055          ASL             A
000056          TAY
000057          LDA             %3+1,Y              ;Get switch address from table
000058          PHA             %3,Y               ; and push onto stack
000059          LDA             %3,Y
000060          PHA
000061          .IF             "%4" <> ""          ;If PARM4 is omitted,
000062          RTS             ; Exit to code
000063          .ENDC          ;Otherwise, drop through
000064 $010          .ENDM
000065
000066 ;
000067 ;          INCREMENT WORD MACRO
000068 ;
000069
000070          .MACRO          INW
000071          INC             %1
000072          BNE             $210
000073          INC             %1+1
000074 $210          .ENDM
000075
000076 ;
000077 ;          INCREMENT ADDRESS MACRO
000078 ;
000079 ;          INCREMENTS 3 BYTE ADDRESS
000080 ;
000081
000082          .MACRO          INCADR
000083          INC             %1
000084          BNE             $310

```



```
000085      INC          %1+1
000086      BNE          $310          ;Bank overflow ?
000087      SEC
000088      ROR          %1+1          ;Yes
000089      INC          %1+1+1400    ;Increment X byte
000090      $310      .ENDM
000091
000092      .MACRO        SET_1MHZ
000093
000094      LDA          E_REG
000095      ORA          #BITON7        ;Set 1 MHZ mode
000096      STA          E_REG
000097      .ENDM
000098
000099      .MACRO        SET_2MHZ
00100
00101      LDA          E_REG
00102      AND          #07F          ;Set 2 MHZ mode
00103      STA          E_REG
00104      .ENDM
00105
00106      .PROC          RS232
00107
00108      ;
00109      ;      SOS GLOBAL DATA AND SUBROUTINES
00110      ;
00111      ALLOCSIR      .EQU          1913      ;SOS interrupt allocation manager
00112      DEALCSIR     .EQU          1916      ;SOS interrupt deallocation manager
00113      SYSERR       .EQU          1928      ;SOS error return
00114      ;
00115      ;      SOS Error Codes
00116      ;
00117      XREQCODE     .EQU          20          ;Invalid request code
00118      XCTLCODE    .EQU          21          ;Invalid control/status code
00119      XCTLPARM     .EQU          22          ;Invalid control/status param
00120      XNOTOPEN    .EQU          23          ;Device not open
00121      XNOTAVIL    .EQU          24          ;Device not available
00122      XNORESRC    .EQU          25          ;Resource not available
00123      XBADOP      .EQU          26          ;Invalid operation for device
00124      ;
00125      ;      HARDWARE I/O ADDRESSES
00126      ;
00127      ACIADATA     .EQU          0C0F0      ;ACIA DATA REGISTER
00128      ACIASTAT    .EQU          0C0F1      ;ACIA STATUS REGISTER
00129      ACIACMD     .EQU          0C0F2      ;ACIA COMMAND REGISTER
00130      ACIACTL    .EQU          0C0F3      ;ACIA CONTROL REGISTER
00131      E_REG       .EQU          0FFDF      ;ENVIRONMENT REGISTER
00132      B_REG       .EQU          0FFEF      ;BANK REGISTER
00133      ;
00134      ;      GENERAL EQUATES
00135      ;
00136      TRUE        .EQU          80
00137      FALSE       .EQU          00
00138      BITON0     .EQU          01
00139      BITON1     .EQU          02
00140      BITON2     .EQU          04
00141      BITON3     .EQU          08
00142      BITON4     .EQU          10
00143      BITON6     .EQU          40
00144      BITON7     .EQU          80
00145      ASC_LF     .EQU          0A
00146      ASC_FF     .EQU          0C
00147      ASC_CR     .EQU          0D
00148      ;
00149      .PAGE
00150
00151      .WORD        0FFFF
00152      .WORD        73.
00153      .ASCII      "(C) Apple Computer 1981, 1982, 1983.  "
00154      .ASCII      "Built-in Serial Port RS-232 Driver."
00155
00156      ;-----
00157      ;
00158      ;      DEVICE INFORMATION BLOCK
00159      ;
00160      ;-----
00161      ;      DEVICE HEADER BLOCK
00162      ;-----
00163
00164      IDBLK       .WORD          0000      ;LINK TO NEXT DEVICE HANDLER
00165      .WORD        RS_MAIN          ;ENTRY POINT ADDRESS
00166      .BYTE        6                ;LENGTH OF DRIVER NAME
00167      .ASCII      ".RS232          "      ;DRIVER NAME
00168      .BYTE        80,00,00         ;DEV NUM, DEV SLOT, DEV UNIT
00169      .BYTE        DEVTYPE          ;DEVICE TYPE
00170      .BYTE        SUBTYPE          ;DEV SUBTYPE
00171      .BYTE        00                ;FUTURE USE
00172      .WORD        0000             ;BLOCK COUNT-NOT USED
00173      .WORD        MANID            ;MANUFACTURER ID
00174      .WORD        RELEASE          ;RELEASE NUMBER-BCD
00175
00176      ;-----
00177      ;      DEVICE CONFIGURATION BLOCK
```



```
000178 ;-----
000179
000180 CNFGBLK      .WORD      12.          ;CONFIGURATION BLOCK LENGTH
000181
000182 DCB          .BYTE      06          ;BAUD RATE - 300
000183          .BYTE      22          ;Data format
000184 ;CTL - Hi nybble
000185 ;CMD - Lo nybble
000186          .BYTE      00          ;Carriage return delay
000187          .BYTE      00          ;Line feed delay
000188          .BYTE      00          ;Form feed delay
000189          .BYTE      00          ;00 - no protocol
000190 ;80 - XON/XOFF
000191 ;40 - ENQ/ACK
000192          .BYTE      13          ;Character to use as XOFF (or ENQ)
000193          .BYTE      11          ;Character to use as XON (or ACK)
000194          .BYTE      223.        ;Buffer level which triggers XOFF
000195          .BYTE      132.        ;Buffer level which triggers XON
000196          .BYTE      80.         ;Character count for ENQ/ACK
000197          .BYTE      00          ;Hardware handshake support
000198
000199 DCB_LN       .EQU        *-DCB
000200
000201          .ASCII      "(C) Apple Computer Inc. 1983"
000202
000203          .PAGE
000204 ;
000205 ;   SOS Device Handler Interface
000206 ;
000207
000208 SOSINT       .EQU        0C0
000209 REQCODE      .EQU        SOSINT+0   ;SOS request code
000210 BUFFER       .EQU        SOSINT+2   ;Buffer pointer
000211 REQCNT       .EQU        SOSINT+4   ;Requested count/Byte count
000212 CTLSTAT      .EQU        SOSINT+2   ;Control/status code
000213 CSLIST       .EQU        SOSINT+3   ;Control/status list pointer
000214 RETPTR       .EQU        SOSINT+8   ;Returned count pointer
000215
000216
000217 ;
000218 ;   Zero Page Storage
000219 ;
000220
000221 ZPGSAVE      .EQU        SOSINT+0A   ;Saved zero page storage
000222
000223 ZPGTEMP      .EQU        ZPGSAVE+00  ;Temporary zero page storage
000224
000225 OPRODPTR     .EQU        0E1         ;Producer pointer
000226 ICSMRPTR     .EQU        0E2         ;Consumer pointer
000227 RETCNT       .EQU        0E3         ;Returned byte count word
000228
000229
000230 ;
000231 ;   Private Variable Storage
000232 ;
000233
000234 SIRADDR      .WORD      SIRTABLE
000235 SIRTABLE     .BYTE      1,0         ;ACIA resource
000236          .WORD      ACIAMIH
000237 MIHBANK      .BYTE      0
000238 SIRCOUNT    .EQU        *-SIRTABLE
000239
000240 OPENFLG      .BYTE      FALSE       ;Device open flag
000241 IS_NEWLINE   .BYTE      FALSE       ;Bit 7 (1=new line mode)
000242 NEWLINE      .BYTE      00         ;Newline character
000243 IN_PROG      .BYTE      00         ;Bit 7 (1=XOFF in progress)
000244 ;Bit 6 (1=XOFF needs to be sent)
000245 SEND_XON     .BYTE      00         ;Bit 7 (1=XON needs to be sent)
000246 RTS_FALSE    .BYTE      00         ;Bit 7 (1=RTS false)
000247 NO_OUTPUT    .BYTE      00         ;Bit 7 (1=suspend output)
000248 DLYCNT       .BYTE      00         ;Delay count for MIH
000249 BRK_CNT      .BYTE      00         ;Interval count for Break signal
000250 CHAR_OUT     .BYTE      00         ;Output character count for ENQ/ACK
000251 IN_PROG1     .BYTE      00         ;Bit 7 (1=ENQ in progress)
000252
000253 ;
000254 ;   Device control parameters
000255 ;
000256
000257 CNTL_PARAM   .BYTE      15.        ;List length
000258
000259 BAUD         .BYTE      00         ;BAUD RATE
000260 DFORMAT      .BYTE      00         ;Data format
000261 ;CTL - Hi nybble
000262 ;CMD - Lo nybble
000263 CRDELAY      .BYTE      00         ;Carriage return delay
000264 LFDELAY      .BYTE      00         ;Line feed delay
000265 FFDELAY      .BYTE      00         ;Form feed delay
000266 PROTOCOL     .BYTE      00         ;00 - none
000267 ;80 - XON/XOFF
000268 ;40 - ENQ/ACK
000269 CTLCHR1      .BYTE      00         ;Character to use as XOFF (or ENQ)
000270 CTLCHR2      .BYTE      00         ;Character to use as XON (or ACK)
```



```

000271 MAXBUF      .BYTE      00          ;Buffer level which triggers XOFF
000272 ;          (or RTS false)
000273 MINBUF      .BYTE      00          ;Buffer level which triggers XON
000274 ;          (or RTS true)
000275 CHARCNT     .BYTE      00          ;Character count for ENQ/ACK
000276 HDW_HSHAKE   .BYTE      00          ;Hardware handshake
000277 ;          Bit 7 (1=enabled)
000278 RD_IMMEDIATE .BYTE      00          ;Bit 7 (1=read immediate mode)
000279 STAT_REG      .BYTE      00          ;Status reg - saved from last interrupt
000280 STAT_LATCH    .BYTE      00          ;Latched status bits - cleared by reset
000281 ;          or status request-1
000282 ;Bit 0 (1=parity error)
000283 ;Bit 1 (1=framing error)
000284 ;Bit 2 (1=overrun)
000285 ;Bit 5 (1=DCD went false)
000286 ;Bit 6 (1=DSR went false)
000287 ;Bit 7 (1=input character lost)
000288
000289 CNTL_LN       .EQU        *-CNTL_PARAM
000290
000291 ;
000292 ;          Data Buffers
000293 ;
000294
000295 OBUFCNT       .BYTE      0           ;Local output buffer byte count
000296 OSPPROPTR     .BYTE      0           ;Producer buffer pointer
000297 OCSMRPTR     .BYTE      0           ;Consumer buffer pointer
000298 OLOCBUF      .BLOCK     0100,0       ;Local output buffer
000299
000300 IBUFCNT       .BYTE      0           ;Local input buffer byte count
000301 ISCSMRPTR    .BYTE      0           ;Input consumer pointer
000302 IPRODPTR     .BYTE      0           ;Input producer pointer
000303 ILOCBUF      .BLOCK     0100,0       ;Local input buffer
000304
000305 .PAGE
000306 ;-----
000307 ;
000308 ;          RS232 DRIVER - MAIN ENTRY POINT
000309 ;
000310 ;-----
000311
000312 RS_MAIN       .EQU        *
000313 SWITCH       REQCODE,8,RS_REQSW
000314
000315
000316 BADREQ       LDA          #XREQCODE   ;Invalid request code
000317 JSR          SYSERR
000318
000319
000320 NOTOPEN      LDA          #XNOTOPEN   ;Device not open
000321 JSR          SYSERR
000322
000323
000324 RS_REQSW     .EQU        *           ;RS232 driver request switch
000325 .WORD       RS_READ-1
000326 .WORD       RS_WRITE-1
000327 .WORD       RS_STAT-1
000328 .WORD       RS_CNTL-1
000329 .WORD       BADREQ-1
000330 .WORD       BADREQ-1
000331 .WORD       RS_OPEN-1
000332 .WORD       RS_CLOSE-1
000333 .WORD       RS_INIT-1
000334
000335 .PAGE
000336 ;-----
000337 ;
000338 ;          RS232 Driver -- Initialization Request
000339 ;
000340 ;-----
000341
000342 RS_INIT      .EQU        *
000343
000344 LDA          #FALSE
000345 STA          OPENFLG   ;Set serial port to not open
000346 CLC
000347 RTS          ;Insure carry clear for load program
000348
000349 .PAGE
000350 ;-----
000351 ;
000352 ;          RS232 Driver -- Open Request
000353 ;
000354 ;-----
000355
000356 RS_OPEN      .EQU        *
000357 BIT          OPENFLG   ;Serial Port open?
000358 BPL          $010     ; No
000359 LDA          #XNOTAVIL
000360 JSR          SYSERR
000361
000362 $010        LDA          B_REG
000363 AND          #0F

```



```

000364          STA          MIHBANK          ;Set interrupt handler bank
000365          LDA          #SIRCOUNT
000366          LDX          SIRADDR
000367          LDY          SIRADDR+1
000368          JSR          ALLOCSIR          ;Allocate the ACIA
000369          BCS          $020
000370
000371          LDX          #DCB_LN-1          ;Copy Device Configuration Block
000372 ; into device control parameters
000373
000374 $015          LDA          DCB,X
000375          STA          CNTL_PARAM+1,X
000376          DEX
000377          BPL          $015
000378
000379          LDA          #0
000380          STA          IS_NEWLINE          ;Set newline mode to False
000381          STA          NEWLINE          ;Clear newline character
000382          STA          RD_IMMEDIATE          ;Read immediate mode off
000383          STA          IN_PROG          ;XOFF in progress flag off
000384          STA          SEND_XON          ;Send XON flag off
000385
000386          JSR          CNTL00          ;Set up ACIA
000387          LDA          #TRUE          ; and clear STAT_REG, STAT_LATCH,
000388 ; RTS_FALSE, NO_OUTPUT, CHAR_OUT,
000389 ; IN_PROG1, DLYCNT and BRK_CNT
000390          STA          OPENFLG          ;Set serial port open
000391          RTS
000392
000393 $020          LDA          #XNORESRC
000394          JSR          SYSERR
000395          .PAGE
000396 ;-----
000397 ;
000398 ;          RS232 Driver -- Close Request
000399 ;
000400 ;-----
000401
000402 RS_CLOSE      .EQU          *
000403          ASL          OPENFLG          ;Serial Port open?
000404          BCS          $05          ; Yes
000405          JMP          NOTOPEN
000406
000407 $05          LDA          OBUFCNT          ;Wait for write completion
000408          ORA          DLYCNT          ; and delay complete
000409          BNE          $05
000410
000411          PHP          ;Save interrupt status
000412          SEI          ;Disable interrupt system
000413          SET_1MHZ
000414          LDA          ACIACMD          ACIACMD
000415          AND          #0F0          ;Disable Rcv/Xmit Interrupt
000416          STA          ACIACMD          ;DTR off, RTS off
000417          LDA          ACIASTAT          ;Clear any prior interrupt
000418          PLP          ;Restore interrupt status
000419
000420          LDA          #SIRCOUNT
000421          LDX          SIRADDR
000422          LDY          SIRADDR+1
000423          JSR          DEALCSIR          ;Deallocate the ACIA
000424          RTS
000425
000426          .PAGE
000427 ;-----
000428 ;
000429 ;          RS232 Driver -- Read Request
000430 ;
000431 ;-----
000432
000433 RS_READ       .EQU          *
000434          BIT          OPENFLG          ;Serial Port open?
000435          BMI          $05
000436          JMP          NOTOPEN
000437
000438 $05          LDA          ISCSMRPTR          ;Get CSMRPTR from driver storage
000439          STA          ICSMRPTR          ;Put in temporary zero page
000440          LDY          #00          ;Prevent offset
000441          STY          RETCNT          ;Zero return count
000442          STY          RETCNT+1
000443
000444          LDA          #0FF          ;One's complement count
000445          EOR          REQCNT
000446          STA          REQCNT
000447          LDA          #0FF
000448          EOR          REQCNT+1
000449          STA          REQCNT+1
000450
000451 $010          INC          REQCNT          ;Increment count
000452          BNE          $015          ;Is count zero ?
000453          INC          REQCNT+1
000454          BEQ          $099          ;Yes, terminate
000455
000456 $015          LDA          IBUFCNT          ;Is input buffer empty ?

```



```

000457         BNE          $020                ;No, continue
000458         BIT          RD_IMMEDIATE        ;Is read immediate mode set ?
000459         BPL          $015                ;No, loop until character received
000460         BMI          $099                ;Yes, terminate
000461
000462 $020      LDY          #0
000463         LDX          ICSPTR
000464         LDA          ILOCBUF,X              ;Get char from local input buffer
000465         STA          (BUFFER),Y           ;Send to user buffer
000466         PHA
000467         INCADR        BUFFER              ;Save character on stack
000468         INC          ICSPTR              ;Increment addr - user buffer pointer
000469         DEC          IBUCNT
000470         INW          RETCNT
000471
000472         LDA          MINBUF                ;Check if below min buffer level
000473         CMP          IBUCNT              ;          (IBUCNT < MINBUF ?)
000474         BCC          $025                ;No, continue
000475
000476         BIT          IN_PROG              ;Yes, XOFF in progress ?
000477         BMI          $022                ;Yes, send XON
000478
000479         BIT          RTS_FALSE            ;Is RTS false ?
000480         BPL          $025                ;No, continue
000481
000482         PHP
000483         SEI
000484         SET_1MHZ
000485         LDA          ACIACMD              ;Save interrupt status
000486         AND          #0F2                ;Disable interrupt system
000487         ORA          #05                 ;Yes, set 1 MHZ mode
000488         STA          ACIACMD              ;Set RTS true and
000489         LDA          #0                   ; enable xmit interrupt
000490         STA          RTS_FALSE            ;Set to [xxxx01x1]
000491         SET_2MHZ
000492         PLP
000493         JMP          $025                ;Clear RTS_FALSE
000494                                     ;Set 2 MHZ mode
000495 $022      LDA          #80                 ;Restore interrupt status
000496         STA          SEND_XON            ;Send XON
000497         JSR          PRIME_OUT           ;Set flag
000498                                     ;Prime output routine
000499 $025      PLA
000500         BIT          IS_NEWLINE           ;Retrieve character from stack
000501         BPL          $010                ;Is newline mode set ?
000502         CMP          NEWLINE            ;No, get next char
000503         BEQ          $099                ;Yes, is char terminator ?
000504         JMP          $010                ;If yes, terminate
000505                                     ;No, get next char
000506 $099      LDY          #0
000507         LDA          ICSPTR              ;Terminate
000508         STA          ICSPTR              ;Save pointer
000509
000510         LDA          RETCNT              ;Get count of returned bytes
000511         STA          (RETPTR),Y          ;Send to user
000512         LDA          RETCNT+1
000513         INY
000514         STA          (RETPTR),Y
000515
000516         RTS
000517                                     ;Return to user
000518         .PAGE
000519 ;-----
000520 ;
000521 ;       RS232 Driver -- Write Request
000522 ;
000523 ;-----
000524
000525 RS_WRITE    .EQU          *
000526         BIT          OPENFLG            ;Serial Port open?
000527         BMI          $05
000528         JMP          NOTOPEN
000529
000530
000531 $05      LDA          OSPRODPTR          ;Get PRODPTR from driver storage
000532         STA          OPRODPTR          ;Put in temporary zero page
000533
000534         LDA          #0FF                ;One's complement count
000535         EOR          REQCNT
000536         STA          REQCNT
000537         LDA          #0FF
000538         EOR          REQCNT+1
000539         STA          REQCNT+1
000540
000541 $010      INC          REQCNT            ;Increment count
000542         BNE          $030                ;Is count zero ?
000543         INC          REQCNT+1
000544         BNE          $030                ;No
000545
000546         JSR          PRIME_OUT           ;Prime consumer
000547         LDA          OPRODPTR          ;Save producer pointer in driver
000548         STA          OSPRODPTR
000549         RTS
000549                                     ;Return to user

```



```

000550
000551 $030      LDX      OBUFCNT      ;Is local output buffer full ?
000552          INX
000553          BNE      $040          ;No
000554
000555          JSR      PRIME_OUT      ;Local buffer is full, prime consumer
000556          JMP
000557
000558 $040      LDY      #00
000559          LDA      (BUFFER),Y      ;Get character from user buffer
000560          INCADR      BUFFER      ;Increment addr - user buffer ptr
000561
000562          LDX      OPRODPTR      ;Get producer pointer
000563          STA      OLOCBUF,X      ;Store character in local buffer
000564          INC      OPRODPTR      ;Advance local buffer
000565          INC      OBUFCNT      ;Advance count
000566          BNE      $010          ;Branch always taken
000567
000568          .PAGE
000569
000570 ;-----
000571 ;
000572 ;       RS232 Driver -- Status Request
000573 ;
000574 ;-----
000575
000576 RS_STAT      .EQU      *
000577          BIT      OPENFLG      ;Serial Port open?
000578          BMI      $05
000579          JMP      NOTOPEN
000580 $05          SWITCH      CTLSTAT,3,STATSW
000581
000582
000583 BADCTL      LDA      #XCTLCODE      ;Invalid control code
000584          JSR      SYSERR
000585
000586
000587 STATSW      .WORD      STAT00-1
000588          .WORD      STAT01-1
000589          .WORD      STAT02-1
000590          .WORD      STAT03-1
000591
000592 STAT00      RTS          ;0 -- NOP
000593
000594
000595 STAT01      LDY      #0          ;1 -- Retrieve device control
000596 ; parameters (including RD_IMMEDIATE
000597 ;       STAT_REG and STAT_LATCH)
000598          LDA      (CSLIST),Y
000599          CMP      CNTL_PARAM
000600          BCS      $01          ; Check for room in status list
000601          ; >= OK
000602
000603          LDA      #XCTLPARM
000604          JSR      SYSERR      ; < NG
000605
000606 $01          LDY      #CNTL_LN-1
000607          PHP
000608          SEI          ;Save interrupt status
000609          ;Disable interrupt system
000610
000611          LDA      CNTL_PARAM,Y
000612          STA      (CSLIST),Y
000613          BPL      $05
000614
000615          INY
000616          STY      STAT_LATCH      ;Clear status latch bits
000617          PLP          ;Restore interrupt status
000618          RTS
000619
000620 STAT02      LDY      #0          ;2 -- Get newline character
000621
000622          LDA      IS_NEWLINE
000623          STA      (CSLIST),Y
000624          INY
000625          LDA      NEWLINE
000626          STA      (CSLIST),Y
000627
000628          RTS
000629
000630 STAT03      LDY      #0          ;3 -- Retrieve driver buffer info
000631
000632          LDA      #OFF          ;Output buffer size
000633          JSR      CNTOUT
000634          LDA      OBUFCNT      ;Number of chars in output buffer
000635          JSR      CNTOUT
000636          LDA      #OFF          ;Input buffer size
000637          JSR      CNTOUT
000638          LDA      IBUFCNT      ;Number of chars in input buffer
000639          JSR      CNTOUT
000640
000641          RTS
000642

```





```

000643 CNTOUT      STA      (CSLIST),Y
000644           INY
000645           LDA      #0           ; high byte (0)
000646           STA      (CSLIST),Y
000647           INY
000648
000649           RTS
000650
000651           .PAGE
000652 ;-----
000653 ;
000654 ;       RS232 Driver -- Control Request
000655 ;
000656 ;-----
000657
000658 RS_CNTRL      .EQU      *
000659           BIT      OPENFLG      ;Serial Port open?
000660           BMI      $05           ; Ok
000661           JMP      NOTOPEN
000662 $05          SWITCH     CTLSTAT,3,CNTLSW
000663           JMP      BADCTL
000664
000665
000666 CNTLSW       .WORD     CNTL00-1
000667           .WORD     CNTL01-1
000668           .WORD     CNTL02-1
000669           .WORD     CNTL03-1
000670
000671
000672 CNTL00      .EQU      *           ;0 -- Reset device
000673
000674           BIT      IN_PROG      ;XOFF in progress ?
000675           BPL      $020        ;No, continue
000676
000677           LDA      #80           ;Yes, send XON
000678           STA      SEND_XON    ;Set flag
000679           JSR      PRIME_OUT   ;Prime output routine
000680
000681 $015        BIT      SEND_XON    ;Wait until XON gets out
000682           BMI      $015
000683
000684 $020        PHP              ;Save interrupt status
000685           SEI              ;Disable interrupt system
000686           LDA      BAUD        ;Validate data rate
000687           AND      #00F
000688           STA      BAUD
000689
000690           SET_1MHZ
000691
000692           LDA      #0
000693           STA      IBUFCNT      ;Zero Input Buffer count
000694           STA      OBUFCNT      ;Zero Output Buffer count
000695           STA      DLYCNT      ;Zero delay count
000696           STA      BRK_CNT     ;Zero interval count
000697
000698           STA      OSPRODPTR    ;Zero pointers
000699           STA      OCSMRPTR
000700           STA      ISCSMRPTR
000701           STA      IPRODPTR
000702
000703           STA      RTS_FALSE   ;Clear RTS false flag
000704           STA      NO_OUTPUT   ;Clear suspend output flag
000705           STA      CHAR_OUT    ;Zero output character count
000706           STA      IN_PROG1   ;ENQ in progress flag off
000707           STA      STAT_LATCH  ;Clear status latch bits
000708           LDA      ACIASTAT
000709           STA      STAT_REG    ;Save status reg
000710
000711           LDA      DFORMAT      ;Validate data format
000712           AND      #0E0
000713           ORA      #BITON4     ;Set receiver clock source to internal
000714           ORA      BAUD
000715           LDX      #03
000716           CPX      BAUD       ;If data rate is 110 baud
000717           BNE      $025
000718
000719           ORA      #BITON7     ; force two stop bits
000720
000721 $025        STA      ACIACTL    ;Set up ACIA control register
000722           LDA      DFORMAT
000723           ASL      A
000724           ASL      A
000725           ASL      A
000726           ASL      A
000727           AND      #0E0
000728           ORA      #09         ;Xmit disabled, Rcv enabled
000729 ;DTR and RTS on
000730           STA      ACIACMD     ;Set up ACIA command register
000731
000732           PLP              ;Restore interrupt status
000733           RTS
000734
000735

```



```

000736 CNTL01      LDY          #0                ;1 -- Load device control parameters
000737 ; except STAT_REG and STAT_LATCH
000738          LDA          (CSLIST),Y
000739          CMP          CNTL_PARAM          ;Check length of control list
000740          BEQ          $01                ; = OK
000741
000742          LDA          #XCTLPARM
000743          JSR          SYSERR              ; NG
000744
000745 $01         LDY          #CNTL_LN-3
000746
000747 $05         LDA          (CSLIST),Y
000748          STA          CNTL_PARAM,Y
000749          DEY
000750          BPL          $05
000751
000752          JSR          CNTL00              ;Set up ACIA
000753
000754          RTS
000755
000756 CNTL02      .EQU          *                ;2 -- Set New Line Character
000757
000758          LDY          #0
000759          LDA          (CSLIST),Y
000760          STA          IS_NEWLINE
000761          INY
000762          LDA          (CSLIST),Y
000763          STA          NEWLINE
000764
000765          RTS
000766
000767 CNTL03      .EQU          *                ;3 -- Transmit Break
000768
000769 $05         LDA          OBUFCNT          ;Wait for write completion
000770          BNE          $05
000771
000772          TAY
000773          LDA          (CSLIST),Y          ;Get number of break intervals
000774          BMI          $050              ;Too large, return
000775          BEQ          $050              ;Zero, return
000776          CMP          #101.            ;Check if > 100 (23.3 sec)
000777          BCS          $050              ;Too large, return
000778
000779          STA          BRK_CNT            ;Save interval count
000780          PHP
000781          SEI
000782          SET_1MHZ
000783          LDA          ACIACMD          ;Transmit Break
000784          ORA          #0C
000785          STA          ACIACMD
000786          LDA          #0
000787          STA          RTS_FALSE
000788          PLP
000789
000790 $010        LDY          #181.            ;This double loop takes 233 ms
000791          LDX          #0                ; in 1 MHz mode
000792 $015        DEX
000793          BNE          $015
000794          DEY
000795          BNE          $015
000796
000797          DEC          BRK_CNT
000798          BNE          $010              ;Loop for interval count
000799
000800          JSR          PRIME_OUT          ;Prime output routine
000801
000802 $050        RTS
000803
000804          .PAGE
000805 ;-----
000806 ;
000807 ; ACIA MASTER INTERRUPT HANDLER
000808 ;
000809 ;-----
000810
000811 ACIAMIH     .EQU          *
000812
000813          STY          STAT_REG          ;Save current status reg
000814
000815          TYA
000816          AND          #BITON3
000817          BEQ          $010              ;Check receiver data reg full
000818          ;No, continue
000819          TYA
000820          AND          #67
000821          ORA          STAT_LATCH
000822          STA          STAT_LATCH
000823          JMP          RS_IN
000824
000825 $010        TYA
000826          AND          #60
000827          ORA          STAT_LATCH
000828          STA          STAT_LATCH
000828          ;Latch status bits

```



```

000829          JMP          RS_OUT
000830
000831  RS_IN          .EQU          *                ;Receive next character
000832
000833          SET_1MHZ
000834          LDX          ACIADATA                ;Read character
000835          SET_2MHZ
000836          TXA
000837
000838          BIT          PROTOCOL                ;Is XON/XOFF protocol mode set?
000839          BPL          $016                    ;No, continue
000840
000841          CMP          CTLCHR1                ;Yes, check for XOFF
000842          BNE          $010                    ;No
000843
000844          LDA          #TRUE                    ;Yes, suspend output
000845          STA          NO_OUTPUT
000846          JMP          RS_OUT
000847
000848  $010          CMP          CTLCHR2                ;Check for XON
000849          BNE          $015                    ;No
000850
000851          LDA          #FALSE                    ;Yes, resume output
000852          STA          NO_OUTPUT
000853          BEQ          RS_OUT                    ;Always taken
000854
000855  $015          LDX          IBUFCNT                ;Check if max buffer level exceeded
000856          CPX          MAXBUF                    ; (IBUFCNT >= MAXBUF ?)
000857          BCC          $020                    ;No, continue
000858
000859          BIT          IN_PROG                    ;Yes, check if XOFF in progress
000860          BMI          $020                    ;Yes, continue
000861
000862          LDX          #BITON6                    ;No, set XOFF needs to be sent
000863          STX          IN_PROG
000864          BNE          $020                    ;Branch always taken
000865
000866  $016          BVC          $017                    ;Is ENQ/ACK protocol mode set?
000867
000868          CMP          CTLCHR2                ;Yes, check for ACK
000869          BNE          $020                    ;No, continue
000870
000871          LDA          CHARCNT                    ;Yes, reset output char count
000872          STA          CHAR_OUT
000873          LDA          #0
000874          STA          IN_PROG1                ;Clear ENQ in progress
000875          BEQ          RS_OUT                    ;Always taken
000876
000877  $017          BIT          HDW_HSHAKE                ;Is Hardware handshake enabled?
000878          BPL          $020                    ;No, continue
000879
000880          LDX          IBUFCNT                ;Check if max buffer level exceeded
000881          CPX          MAXBUF                    ; (IBUFCNT >= MAXBUF ?)
000882          BCC          $020                    ;No, continue
000883
000884          LDX          BRK_CNT                    ;Check for Break in progress
000885          BNE          $020                    ;Yes, continue (can't change RTS)
000886
000887          PHA
000888          LDA          #BITON7                    ;No, save character on stack
000889          STA          RTS_FALSE
000890          SET_1MHZ
000891          LDA          ACIACMD                    ;Set RTS to false
000892          AND          #0F3                    ; Xmit interrupt will be disabled
000893          STA          ACIACMD                    ; ACIA set to [xxxx00xx]
000894          SET_2MHZ
000895          PLA
000896          ;Retrieve character from stack
000897  $020          LDX          IBUFCNT                ;Is buffer full ?
000898          INX
000899          BNE          $025                    ;No, continue
000900
000901          LDA          #BITON7                    ;Yes, latch char lost bit
000902          ORA          STAT_LATCH
000903          STA          STAT_LATCH
000904          BMI          RS_OUT                    ;Always taken
000905
000906  $025          LDX          IPRODPTX                ;Address in local buffer to store data
000907          STA          ILOCBUF,X                ;Store char in local input buffer
000908          INC          IBUFCNT
000909          INC          IPRODPTX
000910
000911  RS_OUT        .EQU          *                ;Output next character
000912
000913          LDA          BRK_CNT                    ;Check for Break in progress
000914          BEQ          $001                    ;No, continue
000915          JMP          RETURN                    ;Yes, return
000916
000917  $001          BIT          HDW_HSHAKE                ;Hardware handshake mode enabled ?
000918          BPL          $003                    ;No, continue
000919
000920          BIT          RTS_FALSE                    ;Yes, check for RTS false
000921          BPL          $002                    ;RTS true, continue

```



```
000922          JMP          RETURN          ;RTS false, return
000923
000924 $002      LDA          STAT_REG        ;Check DSR and DCD status
000925          AND          #60
000926          BEQ          $003              ;DSR and DCD true, continue
000927
000928          LDA          DLYCNT              ;DSR or DCD false, disable xmit int
000929          BNE          $011              ; unless delay in progress
000930          JMP          D_XMIT
000931
000932 $003      LDA          #BITON4            ;Check xmit data reg empty
000933          BIT          STAT_REG
000934          BNE          $004              ;Reg empty, continue
000935
000936          JMP          E_XMIT              ;Reg not empty, enable xmit interrupt
000937
000938 $004      BIT          IN_PROG            ;XOFF need to be sent ?
000939          BVC          $005              ;No, continue
000940
000941          LDA          #BITON7            ;Yes, set XOFF in progress
000942          STA          IN_PROG
000943          LDA          CTLCHR1
000944          JMP          $020              ;Send XOFF
000945
000946 $005      BIT          SEND_XON          ;XON need to be sent ?
000947          BPL          $010              ;No, continue
000948
000949          LDA          #0
000950          STA          SEND_XON          ;Yes, clear flags
000951          STA          IN_PROG
000952          LDA          CTLCHR2
000953          JMP          $020              ;Send XON
000954
000955 $010      LDA          DLYCNT              ;Any transmit delay in progress ?
000956          BEQ          $015              ;No
000957
000958 $011      DEC          DLYCNT              ;Yes, decrement count
000959          JMP          E_XMIT
000960
000961 $015      LDX          OBUF CNT          ;Is local output buffer count zero ?
000962          BEQ          D_XMIT              ;Yes, disable xmit interrupt and return
000963
000964          BIT          NO_OUTPUT          ;Is output suspended ?
000965          BMI          D_XMIT              ;Yes, disable xmit interrupt and return
000966
000967          BIT          PROTOCOL          ;Is, ENQ/ACK protocol mode set?
000968          BVC          $018              ;No, continue
000969
000970          LDA          CHAR_OUT          ;Yes, check output char count
000971          BNE          $016              ;Count not yet exhausted, send char
000972
000973          BIT          IN_PROG1          ;Check for ENQ in progress
000974          BMI          D_XMIT              ;Yes, disable xmit interrupt and return
000975
000976          LDA          #BITON7            ;No, set ENQ in progress
000977          STA          IN_PROG1
000978          LDA          CTLCHR1
000979          JMP          $020              ;Send ENQ
000980
000981 $016      DEC          CHAR_OUT          ;Decrement output char count
000982 $018      LDX          OCSR PTR          ;No, get consumer pointer
000983          LDA          OLOC BUF, X        ;Get character from buffer
000984          DEC
000985          INC          OCSR PTR
000986
000987 $020      TAX
000988          SET_1MHZ
000989          STX          ACIADATA          ;Send character
000990
000991          CPX          #ASC_CR            ;Check for any delay
000992          BNE          $022
000993          LDA          CRDELAY
000994          JMP          $024
000995
000996 $022      CPX          #ASC_LF            ;Check for any delay
000997          BNE          $023
000998          LDA          LFDELAY
000999          JMP          $024
001000
001001 $023      CPX          #ASC_FF            ;Check for any delay
001002          BNE          E_XMIT
001003          LDA          FFDELAY
001004
001005 $024      STA          DLYCNT
001006
001007 E_XMIT     SET_1MHZ
001008          LDA          ACIACMD          ;Enable transmit interrupt
001009          AND          #0F2
001010          ORA          #05
001011          STA          ACIACMD          ;Set to [xxxx01xl]
001012
001013          RTS
001014          ;Return to user
```



```
001015 D_XMIT      SET_1MHZ
001016           LDA      ACIACMD      ;Disable transmit interrupt
001017           AND      #0F2
001018           ORA      #09           ;Set to [xxxx10x1]
001019           STA      ACIACMD
001020 RETURN      RTS                ;Return to user
001021
001022 PRIME_OUT     .EQU      *        ;Called by Read, Write and Control
001023 ; request routines
001024
001025           PHP                ;Save interrupt status
001026           SEI                ;Disable interrupt system
001027           BIT      RTS_FALSE
001028           BMI      $010       ;Return if RTS false
001029           JSR      E_XMIT     ;Enable transmit interrupt
001030           SET_2MHZ
001031 $010         PLP                ;Restore interrupt status
001032
001033           RTS                ;Return
001034
001035           .END
001036
```

```
; #####
; #   END OF FILE:  RS232.text
; #   LINES       :  1036
; #   CHARACTERS  :  51017
; #   Formatter  :  Assembly Language Reformatter 1.0.2 (07 January 1998)
; #   Author     :  David T. Craig -- 71533.606@compuserve.com -- Santa Fe, New Mexico USA
; #####
```

###